

Nastavení modemu COMTREND VR-3026e v2




1 KROK: zapojení modemu


- 1) adaptér připojte z jedné strany do zásuvky a z druhé strany do modemu, zdička s označením Power
- 2) zapněte modem (tlačítko ON) – rozsvítí se zelená kontrolka
- 3) ethernetový kabel (kabel s širší koncovkou) zapojte jedním koncem do modemu, jedna ze zdiček dle vlastního uvážení s označením LAN1 a druhým koncem do vašeho počítače
- 4) telefonní kabel (s užší koncovkou) zapojte jedním koncem do modemu, zdička s označením DSL a druhým koncem do internetové přípojky ve zdi

2 KROK: nastavení modemu

- 1) otevřete si libovolný internetový prohlížeč, např. Internet Explorer, Firefox atd., smažte všechno v poli adresa a zadejte 10.0.0.138 a potvrďte stisknutím klávesy ENTER
- 2) prohlížeč vás vyzve k zadání přihlašovacího jména a hesla, pokud jste si již dříve přihlašovací hesla nezměnili, zadejte přihlašovací jméno admin a heslo také admin. Přihlašte se kliknutím na OK.



3) zobrazí se vám úvodní stránka webové konfigurace



4) a) v levém svislém menu zvolte položku Advanced Setup a následně WAN Service

b) na pravé straně stránky klikněte na položku EDIT v druhém řádku s označením ppp1 a změňte PPP Username a PPP Password dle



přístupového jména a hesla (tyto údaje Vám byly odeslány emailem + SMS zprávou)

(username=přístupové jméno, password=heslo)

c) dále přepiště údaje v pátém řádku s označením Interval:(second) na 48 a šestém řádku s označením Number of retries: na 8
potvrďte stisknutím tlačítka Next na konci stránky

The screenshot shows the COMTREND Multi-DSL CPE web interface. On the left is a navigation menu with the following items: Device Info, Setup Wizard, IPv6 Enabling, Advanced Setup, WAN Interface, Layer2 Interface, WAN Service, LAN, NAT, Security, Parental Control, Quality of Service, Routing, DNS, DSL, UPnP, DNS Proxy, LAN Bundling, Interface Grouping, Static IP Neighbor, IPSec, Multicast, and SIP ALG. The main content area is titled "PPP Username and Password". It contains a note: "PPP usually requires that you have a user name and password to establish your connection. In the boxes below, er NOTE: IP extension can not be enabled when you enable 3G backup." Below this are input fields for "PPP Username:" (containing "wiapraha"), "PPP Password:" (containing "*****"), and "PPPoE Service Name:". The "Authentication Method:" is set to "CHAP" via a dropdown menu. Further down, there are fields for "Configure Keep-alive (PPP echo-request) Interval and the Number of retries", with "Interval:(second)" set to "48" and "Number of retries:" set to "8". At the bottom, there are three unchecked checkboxes: "Enable Fullcone NAT", "Dial on demand (with idle timeout timer)", and "PPP IP extension".

5) **a)** na pravé straně stránky klikněte na položku EDIT v druhém řádku s označením ppp0.1 a změňte PPP Username a PPP Password dle přístupového jména a hesla, které naleznete ve smlouvě (username=přístupové jméno, password=heslo)

b) dále přepiště údaje v pátém řádku s označením Interval:(second) na 48 a šestém řádku s označením Number of retries: na 8

c) potvrďte stisknutím tlačítka Next na konci stránky



Device Info
Setup Wizard
IPv6 Enabling
Advanced Setup
WAN Interface
Layer2 Interface
WAN Service
LAN
NAT
Security
Parental Control
Quality of Service
Routing
DNS
DSL
UPnP
DNS Proxy
LAN Bundling
Interface Grouping
Static IP Neighbor
IPSec
Multicast
SIP ALG
Wireless
Diagnostics
Management

PPP Username and Password

PPP usually requires that you have a user name and password to establish your connection. In the boxes below, enter the user name and password.
NOTE: IP extension can not be enabled when you enable 3G backup.

PPP Username:
PPP Password:
PPPoE Service Name:
Authentication Method:

Configure Keep-alive (PPP echo-request) Interval and the Number of retries
Interval:(second)
Number of retries:

☐ Enable Fullcone NAT
☐ Dial on demand (with idle timeout timer)
☐ PPP IP extension
☒ Enable NAT
☒ Enable Firewall

3 KROK: nastavení WiFi

- 1) **a)** v levém svislém menu zvolte položku Wireless
- b)** na pravé straně stránky zaškrtněte políčko Enable Wireless
- c)** následně v šestém řádku s označením SSID smažte původní slovo a doplňte WIA-ADSL
- d)** potvrďte tlačítkem Apply/Save

COMTREND Multi-DSL CPE

Wireless -- Basic

This page allows you to configure basic features of the wireless LAN interface. You can enable or disable the wireless LAN interface, hide the network from active scan, restrict the channel set based on country requirements. Click "Apply/Save" to configure the basic wireless options.

☒ Enable Wireless
☐ Hide Access Point
☐ Clients Isolation
☐ Disable WMM Advertise
☐ Enable Wireless Multicast Forwarding (WMF)

SSID:

BSSID:

Country:

Max Clients:

Wireless - Guest/Virtual Access Points:

Enabled	SSID	Hidden	Isolate Clients	Disable WMM Advertise	Enable WMF	Max Clients	BSSID
☐	wl0_Guest1	☐	☐	☐	☐	16	N/A
☐	wl0_Guest2	☐	☐	☐	☐	16	N/A
☐	wl0_Guest3	☐	☐	☐	☐	16	N/A

2) **a)** v levém svislém menu zvolte položku Wireless a následně Security

b) na pravé straně stránky vyberte u políčka

- Select SSID: položku WIA-ADSL
- Network Authentication: WPA2 – PSK
- WPA/WAPI passphrase: vyplňte ručně heslo dle vašeho výběru
- WPA/WAPI Encryption: TKIP+AES

c) potvrďte tlačítkem Apply/Save



Device Info

Setup Wizard

IPv6 Enabling

Advanced Setup

Wireless

Basic

Security

MAC Filter

Wireless Bridge

Advanced

Station Info

Diagnostics

Management

Logout

Wireless -- Security

This page allows you to configure security features of the wireless LAN interface.
You may setup configuration manually
OR
through WiFi Protected Setup(WPS)

WPS Setup

Enable WPS

Enabled

☒ Disable PIN mode

Add Client (This feature is available only when WPA-PSK, WPA2 PSK or OPEN mode is configured)

☒ Push-Button

☐ PIN

Add Enrollee

Set WPS AP Mode

Configured

Setup AP (Configure all security settings with an external registrar)

☒ Push-Button

☐ PIN

Config AP

Device PIN

18836486

[Help](#)

Manual Setup AP

You can set the network authentication method, selecting data encryption, specify whether a network key is required to authenticate to this wireless network and specify the encryption strength. Click "Apply/Save" when done.

Select SSID:

WIA-ADSL

Network Authentication:

WPA2 -PSK

WPA/WAPs passphrase:

[Click here to display](#)

WPA Group Rekey Interval:

0

WPA/WAPs Encryption:

TKIP+AES

WEP Encryption:

Disabled

Apply/Save

6

